



- Step 1:** Cut out straight parts with a circular saw or table saw
- Step 2:** Cut curved parts using a jig saw or band saw
- Step 3:** Cut tapers on slats (jigsaw, band saw, table saw, or jointer)
- Step 4:** Sand or plane edges to remove saw marks
- Step 5:** Round edges with sander or router and round over bit
- Step 6:** Assemble chair, starting with lower section, then adding seat slats, arms, and finally the back



An Adirondack chair can be built in a day. (Photo: Michael Pekovich)